




Square truss TS-300 Roof beam




Side View




Side View




Triangle truss TSV-300




L-300 Ladder truss



Front View





Top View





Linking
 1. From Plate/Flange
 connector for linking
 and Section 2.1.1.1
 for plate to plate
 linking. 2. Notes for
 Plate and Flange
 connector linking

Truss Section List





TS-500 Truss Top Horizontal Truss



TS-400 Pillar Truss



TS-300 Roof Beam Truss



TSV-300

